

I sometimes notice an “overflow” effects in games (when I push the joystick sharply to its extremities, nothing happens on-screen). What should I do?

A new Thrustmapper version (v4.02) and compatible driver (v3.02), resolving these “overflow” issues, are available for download.