

## **Need For Speed™ - Wheel settings**

These settings are necessary to your Thrustmaster wheel with:

- **Need For Speed™ Most Wanted**
- **Need For Speed™ Carbon**

### **For the following wheels:**

- "Ferrari GT 2-in-1 Rumble Force"**
- "Ferrari GT 2-in-1 Force Feedback"**
- "F1 Force Feedback"**
- "ENZO Force Feedback"**
- "ENZO 2-in-1 Racing Wheel"**
- "ENZO Wireless"**
- "Nascar Pro Force Feedback 2"**

- 1) Install the latest driver for your wheel.
- 2) In the Control Panel, click the new "Inverted" tab.  
(The color of the axes changes from green to red.)
- 3) Switch your wheel to 2 axis Mode (= combined pedals)
  - Refer to the User's Manual of your wheel for instructions -The 2 pedals are now combined on "Y Axis"
- 4) Click "Ok", start the game and then access the game's options in order to configure your wheel.

### **For the following wheels:**

- "Rally GT PRO Force Feedback"**
- "RGT PRO Clutch Edition"**

- 1) Switch your wheel to 2 axis Mode (= combined pedals)
  - Refer to the User's Manual of your wheel for instructions -The 2 pedals are now combined on "Y Axis"
- 2) Click "Ok", start the game and then access the game's options in order to configure your wheel.