

How can I manually configure my PS3's IP address?

1. On your PS3, go to the **Settings/Network Settings** menu.
2. Select **Internet Connection Settings** and validate. The following message appears: **If the Internet connection settings are configured the system will be disconnected.** Select **Yes**.
3. Select **Wireless** and then in the **WLAN Settings** menu select **Scan** and then select the SSID **FunAccess**.
4. If you have secured your WiFi network, make sure that you have entered the same security settings.
5. In the **Address Configuration** menu, select **Custom**, then **Manual**.
6. Enter the following settings:

IP address:	192.168.0.5
Subnet mask:	255.255.255.0
Default router:	192.168.0.1
7. Enter the DNS server addresses according to your internet service provider (ISP). Contact your ISP for details or try out the following settings:
 - **Wanadoo/Orange:**
Primary DNS: 80.10.246.2
Secondary DNS: 80.10.246.129
 - **Free:**
Primary DNS: 212.27.32.5
Secondary DNS: 212.27.32.176
 - **Neuf Telecom:**
Primary DNS: 212.30.96.108
Secondary DNS: 213.203.124.146
 - **Cegetel:**
Primary DNS: 194.6.128.3
Secondary DNS: 194.6.128.4
 - **Télé2:**
Primary DNS: 130.244.127.161
Secondary DNS: 130.244.127.162

- **AOL:**
Primary DNS: 205.188.146.146
Secondary DNS: 202.67.95.0
- **Club-Internet:**
Primary DNS: 194.117.200.10
Secondary DNS: 194.117.200.15
- **Liberty Surf:**
Primary DNS: 194.149.160.9
Secondary DNS: 194.149.160.9
- **Alice:**
Primary DNS: 212.216.172.62

These **DNS** details may be modified by your ISP. If the settings listed above do not function properly, please verify them with your ISP.

8. Continue to the following menus and validate these settings:

MTU:	Automatic
Proxy server:	Do not use
UPnP:	Enabled

9. You can then verify the **List of settings** shown on-screen, **Save** them and **Test Connection**.