


How I can separate the pedals axis to configure the wheel in 3-axis mode?

When the wheel is configured for 2 axes (combined mode), if you accelerate and brake at the same time, the effects cancel each other out.

When the wheel is configured for 3 axes (separate mode), if you accelerate and brake at the same time, the effects build on each other for a more realistic driving experience.

You must use the Thrustmapper software to separate the pedal's axes.

- Right-click on the **Thrustmapper** icon on the taskbar. A menu appears.
- Click on **Thrustmapper**.
- In the **Accessory** field, select the wheel you which to use
- In the **Gaming Profile** field, select **Drive Simulators**.
- Click on **Browse...**
- Click on the scroll-down list to the right of the **Explorer**, select **C:** and then select your game's directory.
- Select the executable file that launches the game.
- Click on **Open**.
- Click on **OK** to validate your selection.
- Select the **Axes** tab in the Thrustmapper central column.
- Enable the **Separate** option to configure the wheel in 3-axis mode.



Save the configuration and launch your game.